

9	On ●	Off ○	Fault (0.5s on 0.5s off) 5 time ●	Overcurrent Protection
10	On ●	Off ○	Fault (0.5s on 0.5s off) 7 time ●	Leakage Protection
11	On ●	Off ○	Fault (0.5s on 0.5s off) 9 time ●	Communication Fail

When the red light flickers:

1. One times 0.5s on, 0.5s off :Circuit Board Overheat Protection;
2. Two times 0.5s on, 0.5s off :Under voltage Protection;
3. Three times 0.5s on, 0.5s off :Overvoltage ;
4. Four times 0.5s on, 0.5s off :Undergrounded Protection;
5. Five times 0.5s on, 0.5s off :Overcurrent Protection;
6. Seven times 0.5s on, 0.5s off :Leakage Protection;
7. Nine times 0.5s on, 0.5s off :Communication Fail;

Charge

1. Check the power distribution cable for damage before powering up.
2. Plug the mains plug into the socket.
3. Make sure that the power outlet complies with national standards and that the socket is CEE.
4. Plug the vehicle plug into the socket of your vehicle.
5. Make sure that the vehicle connector is fully inserted until it clicks into place.
6. The charger works automatically, the power lights on and the Charger light flash/1s.



Waiting for charging



Charge complete

1. Disconnect the plug.
2. Disconnect the charging cable.
3. Cover the connector cover to you plug.
4. Insert the charging cable into the carrying case.

Warranty:

Damage caused for the following reasons is not covered by the warranty:

1. Improper handling, installation, use and maintenance by the user.
2. Product falls into the water.

This warranty is for the original purchaser only and is NOT transferable.